




- Installation (GB)
- Installation (F)
- Einbauanleitung (D)
- Installazione (I)
- Instalatie (NL)
- Instalação (P)
- Instalación (E)
- Installation (S)
- Установка (RUS)




Tank Safe (RK.80)
Tank Safe (TS)









ELFAB LIMITED
Alder Road, North Shields, Tyne and Wear NE29 8SD.
UNITED KINGDOM
Free Phone: 00 800 88 22 88 00 (Europe, RoW)
Toll Free (USA): (877) 88 22 880
e-mail: sales@elfab.com http://www.elfab.com

GSS63 APRIL 2004



(GB) Do not use if damaged **(P)** Não usar se avariado
(F) Ne pas utiliser si endommagé **(E)** No utilice en caso de este dañado
(D) Niemals beschädigte berstscheibe einbauen **(S)** Får ej användas, om det är skadat
(I) Non utilizzare se danneggiato **(RUS)** Не пользоваться при повреждениях
(NL) Indien beschadigd niet gebruiken



Ø(mm)	T (Nm) C	Ø(Ins)	T (lbs.ft) C
10	18 ± 2	1/2	25 ± 5
12	30 ± 5	5/8	50 ± 10
16	75 ± 10	3/4	85 ± 20
20	150 ± 25	7/8	140 ± 30
24	260 ± 40	1	210 ± 40
27	370 ± 60	1 1/8	300 ± 60
30	500 ± 90	1 1/4	410 ± 90
33	670 ± 110	1 3/8	550 ± 120
36	870 ± 150	1 1/2	720 ± 150
39	1110 ± 190	1 3/4	1160 ± 230
45	1810 ± 390	2	1730 ± 340